### USAR HulaPoint™ - Ergonomic Mouse PS2/RS232 Encoder



#### **Mature**

mousecoder<sup>™</sup> product specifications

#### **Description**

The USAR HulaCoder™ UR7HCDMP is an easy-to-use single-chip encoder that interfaces an innovative sensor developed by Fujitsu. Together they make the USAR HulaPoint™. Equipped with an advanced motion algorithm, the UR7HCDMP offers low power consumption in a small footprint package. The device can be linked through either the serial or PS/2-type mouse port of the host system.

The UR7HCDMP is compatible with the IBM and Microsoft two-button and the Logitech three-button mouse communication protocols. The device will auto switch between the Serial and the PS/2 mouse communication protocol depending on the port to which the device is actually connected.

Communication through the serial port is half-duplex at a fixed speed of 1200 Baud. PS/2 communication is bidirectional at 10 kbps. The USAR HulaCoder™ implements all commands from and to the system, as defined in the IBM PS/2 Mouse Communication Protocol.

The UR7HCDMP is a CMOS device operating at 4 MHz. The low-power consumption of the IC makes it suitable for battery operated systems. Power in the serial mode, as in any standard mouse, can be drawn from the RS232 lines of the host system.

Custom versions are available to suit a wide range of pointing device applications.

HulaCoder™ is a trademark of USAR Systems, Inc. All other trademarks belong to their respective companies.

#### **Features**


- Equipped with Advanced Motion Control algorithm
- Low power consumption in a 3 to 6
   Volt operating range
- Effortless and accurate cursor control with 10 degree movement in every direction
- Compatible with IBM/Microsoft twobutton and Logitech three-button mouse
- Works with innovative proprietary sensor technology developed by Fujitsu Microelectronics
- Responds to feather-light touch without resistance
- Small 18 pin plastic PDIP and SOIC Packages available
- Autoselectable RS232 or P7S/2 hardware interface
- Customized versions available

#### **Applications**

- Embedded HulaPoints
- Industrial Panels

Instrumentation

#### **Pin Descriptions**




Ordering Code		
Package options	TA=0°C TO +70°C	TA=40°C TO +85°C
18-pin, Plastic Dip	UR7HCDMP-P	UR7HCDMP-CP
18-pin,SOIC	UR7HCDMP-DW	UR7HCDMP-CDW

#### **Functional Description**

The UR7HCDMP consists functionally of five major sections (see Functional Diagram below). These are the Sensor Interface, the Sixteen Bit Timer, the Oscillator Circuit, the PS/2 Communication Port and the RS232 Communication Port. All sections communicate with each other and operate concurrently.

#### **Functional Diagram**



mousecoder<sup>™</sup> product specifications

#### Autoselect

At power-up the USAR HulaCoder™ will execute a power-on reset and determine the mode of operations.

#### PS/2 Mode

At start-up or upon receiving a reset command, Clock and Data lines of the USAR HulaCoder™ can be pulled to a positive level. The UR7HCDMP will then wait between 300 and 500 milliseconds before sending an AAh to the host followed by a device ID of 00h. Then the IC will set itself to its default values, i.e. Incremental Stream Mode with 1:1 scaling, and a report rate of 100 Hz. The device will then disable itself until a command is sent from the host.

#### **Error Handling**

For every correct command or parameter received from the host, the UR7HCDMP sends an Acknowledge (FAh). If an invalid command or parameter is received, the UR7HCDMP issues a Resend Request (FEh). If an invalid input is again received, the device transmits an Error Code (FCh) to the host. Both Error and Resend Request responses are sent by the device within 25 milliseconds. The host may not issue any new commands until either the USAR HulaCoder™ has responded or until 25 milliseconds have elapsed.

#### **Pin Description**

Pin	N	um	be	ers
-----	---	----	----	-----

Mnemonic	DIP	SOIC	TYPE	Name and Function
CHX	1	1	Analog Input	Horizontal Input
RTSIN	2	2	1/0	RTS Sense, Power Save Out
SEROUT	3	3	O, Open Drain	Serial Tx Data
RESETIN	4	4	1	Reset: apply 0 V for orderly start
				up.
GND	5	5	Power	Ground
PS2CLK	6	6	I/O	PS/2 Clock
PS2DAT	7	7	I/O	PS/2 Data
RIGHTSW	8	8	I w/ Pullup	Right Switch: Low = On.
LEFTSW	9	9	I w/ Pullup	<b>Left Switch:</b> Low = On.
MIDDLESW	10	10	I w/ Pullup	Middle Switch: Low=On.
D/A-0	11	11	0	Resolution enhancement
				<b>D/A:</b> LSB.
D/A-1	12	12	0	Resolution enhancement
				D/A
D/A-2	13	13	0	Resolution enhancement
				D/A: MSB.
VCC	14	14	Power	Power Supply
OSCOUT	15	_15	0	Oscillator Output
OSCIN	16	16	<u> </u>	Oscillator Input
PWRON	17	17	0	Sensor Power Strobing
				Control
CHY	18	18	Analog Input	Vertical Input

**USAR Systems, Inc.** 

#### **Pin Description Notes**

The Internal Oscillator has a built-in feedback resistor. Only one (1) external component is needed for Clock generation. USAR recommends a 4.00 MHz Ceramic Resonator with built-in load capacitors.

RIGHTSW, LEFTSW, and MIDDLESW inputs have built-in pull-up resistors. No additional components are required for a three-button design. However, if high levels of ESD and EMI are expected, than series protection resistors (47 Ohms to 1k Ohms) are recommended between the switches and the switches' inputs on the IC.

## USAR HulaCoder™ UR7HCDMP **Mature**

mousecoder<sup>™</sup> product specifications

#### **PS/2 Mode Commands**

When the **Reset Command** (FFh) is enacted, the UR7HCDMP sets the following default parameters: Incremental Stream Mode, 1:1, scaling, disabled, and a report rate of 100 Hz and then sends AAh to the host followed by a device ID of 00h.

The host sends the **Resend Last Data Stream Command** (FEh)

when it detects an error in any
UR7HCDMP transmission. The
device then resends the last output
data stream to the host. This
transmission occurs after a USAR
HulaCoder™ transmission and
before the host enables the
interface allowing the next USAR
HulaCoder™ output.

The **Set Default Status Command** (F6h) re-initializes the device to its condition at power-up.

The **Disable Command** (F5h) stops the device from transmitting all reports. However, the mode does not change; the HulaCoder<sup>™</sup> is still able to respond to commands. If the **Disable**Command is issued while the

**Command** is issued while the device is transmitting a report, the UR7HCDMP immediately stops the transmission and disables itself.

If the USAR HulaCoder™ is in Incremental Stream Mode, the Enable Command (F4h) will allow it to begin data transmission. If the device is in Prompt Mode, the **Enable Command** will update the internal status of the USAR HulaCoder™, but will not allow the device to transmit data to the host either while it is moving or when a button is depressed.

#### **PS/2 Data Format**

The following table shows the data report format. Values are expressed in a Two's Complement Format with a separate sign bit. If there is an overflow of the accumulator, the maximum positive or negative count is reported and the corresponding overflow bit is set.

Byte 1		
b0 b1 b2 b3 b4 b5 b6 b7	Left Button status Right Button Status Middle Button Status Always = 1 X data sign Y data sign X data overflow Y data overflow	1 = depressed 1 = depressed 1 = depressed 1 = negative 1 = negative 1 = overflow 1 = overflow
Byte 2		
b0 b1 b2 b3 b4 b5 b6 b7	X0: LSB of X data X1 X2 X3 X4 X5 X6 X7: MSB of X data	
Byte 3		
b0 b1 b2 b3 b4 b5 b6	Y0: LSB of Y data Y1 Y2 Y3 Y4 Y5 Y6 Y7: MSB of Y data	

#### Status Report Format Table

Byte 1		
b0 b1 b2 b3 b4 b5 b6 b7	Right Button Middle Button Left Button Always = 0 Scaling - 1:1 (0) / 2:1 ( Disable - (0) / enable ( Stream - (0) / prompt (1) Always = 0	1)
Byte 2		
	b0 - 1 Current resolution b2 - 7 Always = 0	setting
Byte 3		
	b0-7 Current sampling	

#### PS/2 Mode Commands, Cont

The USAR HulaCoder™ will respond to the **Set Sampling Rate Command** (F3h) in both Stream and Prompt Modes, but will only update its internal status if the command is enacted while the device is in Stream Mode

The UR7HCDMP responds to the the **Read Device Type Command** (F2h) immediately after the Acknowledge with a 00h.

The **Set Prompt (Remote) Mode Command** (F0h) sets the device to Prompt Mode. Data values are then only reported in response to a **Read Report Command** (EBh).

If the **Set Echo Mode Command** (EEh) is enacted, the

USAR HulaCoder™ will immediately
return any data bytes except FF or

EC.

The **Reset Echo Mode Command** (ECh) returns the device to its previous mode - disabled. If this command occurs while the UR7HCDMP is in either Stream or Prompt Modes, the command is ignored.

The **Read Report Command** (EBh) prompts the USAR HulaCoder™ for a report. The report occurs even if the device did not move or if the status of the switches did not change. The report is sent by the UR7HCDMP following an Acknowledge.

The **Set Incremental Stream Mode Command** (EAh) sets the
USAR HulaCoder™ to Stream Mode
and disables the device.

#### **Sequential Commands**

Unlike normal commands, sequential commands must be enacted with a sequence of commands. If the sequence is not consecutive or is incorrect, the USAR HulaCoder $^{\text{TM}}$  aborts the detection and responds the way it would normally respond to a command.

The individual commands that comprise a sequential command have been designed so that the elements of a sequential command can be sent to the USAR HulaCoder™ via the standard IBM PS/2 BIOS calls and the device only returns a valid response to the Standard Status Request. This ensures that, if the sequential command is sent via the BIOS, the status response will be accurately returned even if the BIOS does error detection. Thus, a programmer can have complete control of the mouse without having to access the device hardware port directly.

The USAR HulaCoder™ implements a special sequential command that can be used to determine its ability to report three buttons. The sequential command is a series of commands to the USAR HulaCoder™ that cause the device to respond to the last command (Read Status) with alternate information.

Sequence of commands:

1. Set Resolution = one count/ mm
Direct: E8H,00H BIOS: INT15H, AX=C203H, BX=0

2. Set Scaling = 1:1

Direct: E6H BIOS: INT15H, AX=C206H, BX=1

3. Set Scaling = 1:1

Direct: E6H BIOS: INT15H, AX=C206H, BX=1

4. Set Scaling = 1:1

Direct: E6H BIOS: INT15H, AX=C206H, BX=1

5. Read Status

Direct: E9H BIOS: INT15H, AX=C206H, BX=0

The response to the Read Status Command is in the form:

Byte 1: Standard Status Information (buttons, scaling, etc.)

Byte 2: Number of mouse buttons (3)

mousecoder<sup>™</sup> product specifications

#### PS/2 Mode Commands, Cont.

The **Status Request Command** (E9h) returns a 3 byte status report.

The **Set Resolution Command** (E8h) controls resolution, and the Set 2:1 Scaling Command (E7h) enables a coarse/fine tracking response. Due to the Advanced Motion Algorithm, Set Resolution and Scaling Command are acknowledged and reported as activated, but their status is ignored. The Set 1:1 Scaling Command (E6h) enables the values of movements to be transmitted to the host without any scaling

#### Serial Mode

Communication through the serial port is half-duplex at a fixed speed of 1200 Baud, 7N2 protocol.


At start-up and after each RTS toggle the USA HulaCoder™ will send a two-character ASCII string "M3" indicating 3-button capability to the host.

A Data Report is sent if motion is detected, or if buttons are pressed or released. Motion is reported relative to the last Report sent, in a Two's Complement Form and eight (8) bit resolution. In other words, the Maximum Motion values are -128 to +127, saturated at min/max for faster speeds. Byte 4 is sent only if the middle button is pressed, held-down, or released.


#### **Serial Data Report Format Table**

X6 X7: MSB of X Data Y6 Y7: MSB of Y Data Right Button Status Left Button Status Always=1	1 = depressed 1 = depressed
X0: LSB of X data X1 X2 X3 X4 X5 Always=0	
Y0: LSB of Y data Y1 Y2 Y3 Y4 Y5 Always=0	
Always = 0 Middle Button Status 1=depressed Always=0	
	X7: MSB of X Data Y6 Y7: MSB of Y Data Right Button Status Left Button Status Always=1  X0: LSB of X data X1 X2 X3 X4 X5 Always=0  Y0: LSB of Y data Y1 Y2 Y3 Y4 Y5 Always=0  Always=0  Always=0  Middle Button Status 1=depressed


#### **HulaPoint™ Sensor Dimensions**



#### HulaPoint™ Evaluation Board Mechanical




#### HulaPoint™ Alternate Kit with Rubber Overlay Material



USAR Datasheet DOC7-DMP-DS-102 **9** 

specifications mousecoder™ product

# Sample **Schematic**



#### **Electrical Specifications for UR7HCDMP**

Absolu	te Max	imum	Ratings

Ratings	Symbol	Value	Unit
Supply Voltage	Vdd	0 to 7.5	V
Input Voltage	Vin	Vss -0.6 to Vdd +0.6	V
Current Drain per Pin	I	20	mA
(not including Vss or Vdd)			
Operating Temperature	Ta	T low to T high	° C
UR7HCDMP-xx		0 to +70	
UR7HCDMP-Cxx		-40 to +85	
Storage Temperature Range	Tstg	-65 to +150	° C
Ambient Temperature Under Bias	Tbias	-55 to +125	°C

DC Electrical Characteristics, Temperature range=T low to T high unless otherwise noted)

Characteristic	Symbol	Min	Тур	Max	Unit
Supply Voltage		3.0	5.0	6.0	V
Output Voltage	Voh	Vdd-0.1	· ·		V
	Vol			0.1	
Input High Voltage	Vih	0.7xVdd	Vdd		V
Input Low Voltage	Vil	Vss		0.2xVdd	V
Input Current		lin		+/- 1	uA
Internal Pull-up Current	Ipup	50	250	500	uA
Supply Current Vdd=0	ldd		2.0	3.5	mA5
Vdc+/-10%, Vss=0					

ymbol	Min	Тур	Max	Unit
OSC				MHz
		4.0		
		4.0		
	DSC 	OSC	4.0	4.0



# For sales information and product literature, contact:

USAR Systems, Inc. 568 Broadway New York, NY 10012 info@usar.com

## http://www.usar.com

Telephone 1 212 226 2042 Telefax 1 212 226 3215

In Japan:

Mitsubishi Electronic Semiconductor Telephone +81 03 5403 0422 E-mail iidamt@hon.mesc.co.jp Contact: Masatoshi Iida

In Singapore:
MetaTech
Telephone +65 748 4844
E-mail Mike.Tiong@metatech.com.sg
Contact: Mike Tiong

In Taiwan:

Koryo Electronics Co., Ltd. Telephone +886-2-2698-1143 E-mail alex.chen@koryo.com.tw Contact: Alex Chen

In Korea:

Bong Woo Corporation Ltd. Tel: +82 2 285-0540~8 Email inchulpark@hotmail.com Contact: I.C. Park

Copyright 1999 USAR Systems, Inc. HulaCoder<sup>TM</sup> and HulaPoint <sup>TM</sup> are trademarks of USAR Systems, Inc. All other trademarks belong to their respective companies.

INTELLECTUAL PROPERTY DISCLAIMER
This specification is provided "as is" with no warranties whatsoever including any warranty of merchantability,

fitness for any particular purpose, or any warranty

otherwise arising out of any proposal, specification or sample.

A license is hereby granted to reproduce and distribute this specification for internal use only. No other license, expressed or implied to any other intellectual property rights is granted or intended hereby. Authors of this specification disclaim any liability, including liability for infringement of proprietary rights, relating to the implementation of information in this specification. Authors of this specification also do not warrant or represent that